


RWF BRON

PARTS MANUAL BRON DL750 PLOW



RWF INDUSTRIES

873 Devonshire Ave., Woodstock,

Ontario N4S 8Z4

Tel: (519) 421-0036

Toll Free: 1-800-263-1060

Fax: (519) 421-0028

Email: parts@rwfbron.com

PLOW BREAKDOWN

TABLE OF CONTENTS


BACKPLATE	1
FRONT MAST	2
UPPER LINK.....	3
REAR LOWER LINK.....	4
FRONT VERTICAL LINK.....	5
SLIDING UPPER LINK	6
LOWER FRONT LINK	7
BLADE HOLDER	8
BLADE LOCK	9
WEDGE LOCK	10
SWING CYLINDERS	11

DL750 PARTS MANUAL TABLE OF CONTENTS

DL750

PARTS MANUAL

LIFT / GRADE CYLINDER	12
FLOAT CYLINDER	13
BLADE LOCK CYLINDER.....	14
DECALS	15



rwf_0052

1 BACKPLATE (32893)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	2	80157	HEX HEAD BOLT
2	2	80584	WASHER
3	2	114851	BOLT SPACER
4	1	116841	PIN ASSEMBLY
5	1	113588	PIN ASSEMBLY
6	2	12006	SWIVEL BUSHING
7	2	80090	HEX HEAD BOLT
8	2	80581	WASHER
9	2	114862	BOLT SPACER
10	2	12266	PIN ASSEMBLY
11	4	80680	STRAIGHT GREASE FITTING
12	4	16311	BUSHING
13	2	9900433	SWING CYLINDER (SEE SECTION 11 FOR ASSEMBLY BREAKDOWN)
14	2	80605	HEX HEAD SOCKET SET SCREW
15	1	143350	BACKPLATE

2 FRONT MAST (40021_J)

DL750

PARTS MANUAL



rwf_0106

2 FRONT MAST (40021_J)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	2	115736	PIN ASSEMBLY
2	5	114851	BOLT SPACER
3	11	80584	WASHER
4	5	80157	HEX HEAD BOLT
5	2	80090	HEX HEAD BOLT
6	2	80581	WASHER
7	2	114862	BOLT SPACER
8	2	113576	PIN ASSEMBLY
9	2	12001	SWIVEL BUSHING
10	5	80680	STRAIGHT GREASE FITTING
11	2	113584	PIN ASSEMBLY
12	6	80165	HEX HEAD BOLT
13	5	12003	SWIVEL BUSHING
14	1	115738	PIN ASSEMBLY
15	1	17853	LIFT / GRADE CYLINDER (SEE SECTION 12 FOR ASSEMBLY BREAKDOWN)
16	1	80682	90° GREASE FITTING
17	1	30017	CLEVIS BRACKET
18	2	16322	CLEVIS KEEPER BAR
19	1	40021	FRONT MAST

3 UPPER LINK (40013_D)

DL750

PARTS MANUAL



rwf_0107

3 UPPER LINK (40013_D)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	12003	SWIVEL BUSHING
2	1	80157	HEX HEAD BOLT
3	1	80584	WASHER
4	1	114851	BOLT SPACER
5	1	113585	PIN ASSEMBLY
6	1	40013	DL750 UPPER LINK
7	2	80680	STRAIGHT GREASE FITTING
8	8	85100	TUBE CLAMP
9	8	80576	WASHER
10	8	80000	HEX HEAD BOLT
11	1	113706	UPPER FRONT LINK CATWALK
12	6	80580	WASHER
13	6	80070	HEX HEAD BOLT

4 REAR LOWER LINK (21934_B)

DL750

PARTS MANUAL



rwf_0110

4 REAR LOWER LINK (21934_B)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	2	80157	HEX HEAD BOLT
2	2	80584	WASHER
3	2	114851	BOLT SPACER
4	2	16310	PIN ASSEMBLY
5	3	80680	STRAIGHT GREASE FITTING
6	1	21934	REAR LOWER LINK
7	2	112755	BUSHING

5 FRONT VERTICAL LINK (21935_C)

DL750

PARTS MANUAL



rwf_0109

5 FRONT VERTICAL LINK (21935_C)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	4	80680	STRAIGHT GREASE FITTING
2	1	80157	HEX HEAD BOLT
3	1	80584	WASHER
4	1	114851	BOLT SPACER
5	1	117304	PIN ASSEMBLY
6	1	21935	FRONT VERTICAL LINK
7	2	12003	SWIVEL BUSHING
8	2	16323	BUSHING

6 SLIDING UPPER LINKS (117301_C) & (21586_F)

DL750

PARTS MANUAL



rwf_0111

6 SLIDING UPPER LINKS (117301_C) & (21586_F)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	3	16062	BUSHING
2	2	80680	STRAIGHT GREASE FITTING
3	1	113579	PIN ASSEMBLY
4	1	114851	BOLT SPACER
5	25	80584	WASHER
6	1	80157	HEX HEAD BOLT
7	1	21586	REAR SLIDING UPPER LINK
8	12	80168	HEX HEAD BOLT
9	1	117301	FRONT SLIDING UPPER LINK WELDMENT
10	12	80519	LOCK NUT
11	1	117175	FLOAT CYLINDER (SEE SECTION 13 FOR ASSEMBLY BREAKDOWN)
12	1	119877	$\frac{1}{8}$ " SHIM
13	1	119876	$\frac{1}{2}$ " SHIM
14	1	119875	$\frac{3}{8}$ " SHIM
15	2	111269	$\frac{1}{4}$ " SHIM

7 LOWER FRONT LINK (40012_F)

DL750

PARTS MANUAL




rwf_0108

7 LOWER FRONT LINK (40012_F)

DL750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	113580	PIN ASSEMBLY
2	2	114851	BOLT SPACER
3	2	80584	WASHER
4	2	80157	HEX HEAD BOLT
5	3	12003	SWIVEL BUSHING
6	4	80680	STRAIGHT GREASE FITTING
7	2	16323	BUSHING
8	1	40012	FRONT BOTTOM LINK
9	1	117176	PIN ASSEMBLY



rwf_0124

8 BLADE HOLDER (30694_M)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	2	80680	STRAIGHT GREASE FITTING
2	1	30694	DL750 BLADE HOLDER
3	14	85099	TUBE CLAMP
4	14	80576	WASHER
5	14	80000	HEX HEAD BOLT
6	1	80070	HEX HEAD BOLT
7	1	124492	DEPTH INDICATOR ASSEMBLY
8	2	80111	HEX HEAD BOLT
9	2	80582	WASHER
10	1	130091	RETAINER PLATE
11	1	138822	SQUARE PIN ASSEMBLY

9 BLADE LOCK

DL750

PARTS MANUAL



rwf_0112

9 BLADE LOCK

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	3	80090	HEX HEAD BOLT
2	3	80581	WASHER
3	3	114862	BOLT SPACER
4	1	12266	PIN ASSEMBLY
5	1	9900441	HITCH PIN
6	1	114617	PIN ASSEMBLY
7	1	12264	PIN ASSEMBLY
8	3	16311	BUSHING
9	1	114615	LOCKING ARM
10	2	80680	STRAIGHT GREASE FITTING
11	1	12001	SWIVEL BUSHING
12	1	9900433	SWING CYLINDER (SEE SECTION 11 FOR ASSEMBLY BREAKDOWN)

10 WEDGE LOCK

DL750

PARTS MANUAL



rwf_0122

2015

10.1


BRON

10 WEDGE LOCK

DL750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	80090	HEX HEAD BOLT
2	1	80581	WASHER
3	1	114862	SPACER
4	1	110734	PIN ASSEMBLY
5	2	16311	BUSHING
6	1	13417	BLADE LOCK CYLINDER (SEE SECTION 14 FOR ASSEMBLY BREAKDOWN)



rwf_0126

11 SWING CYLINDERS (9900433_A)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	12001	SWIVEL BUSHING
2	2	16311	BUSHING
3	1	14126	SEAL KIT
4	1	140234	ROD EYE

12 LIFT / GRADE CYLINDER (17853_E)

DL750

PARTS MANUAL



rwf_0127

2015

12.1


BRON

12 LIFT / GRADE CYLINDER (17853_E)

DL750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	2	12003	SWIVEL BUSHING
2	1	112062	SEAL KIT
3	1	127782	CYLINDER LUG
4	1	136217	LUG- BASE CYLINDER



rwf_0128

13 FLOAT CYLINDER (117175_B)

DL750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	121446	SEAL KIT
2	1	16062	BUSHING
3	1	12003	SWIVEL BUSHING

14 WEDGE LOCK CYLINDER (13417)

DL750

PARTS MANUAL




rwf_0125

14 WEDGE LOCK CYLINDER (13417)

DL750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	80658	COTTER PIN
2	1	80509	STANDARD NUT
3	1	112762	WEDGE
4	1	12494	SEAL KIT
5	1	16909	CYLINDER ASSEMBLY
6	2	16311	BUSHING
7	1	80682	90° GREASE FITTING



rwf_0123

15 DECALS

DL750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	16923	BRON PATENT # DECAL
2	1	11982	NO WELDING DECAL
3	1	117287	LUBRICATE DAILY DECAL
4	2	16879	BRON DECAL
5	4	11983	WARNING SWING AREA DECAL
6	1	15073	SERIAL # PLATE
7	2	80770	RIVET
8	2	141763	BRON DECAL